

Operation & Installation Guide

HME-HAS-DC5-072007

Honeywell

Model / Modèle / Modelo / Modell
2025, 2025E / 2072, 2072E / 2073, 2073E

ANTI  **THEFT SAFE**®

COFFRE-FORT ANTI-EFFRACTION
CAJA FUERTE ANTIRROBO
SAFE MIT DIEBSTAHLSCHUTZ
ANTIDIEFSTAL BRANDKAST

Read These Instructions Very Carefully!
Lire ces instructions très attentivement!
¡Sirvase leer estas instrucciones cuidadosamente!
Bitte lesen Sie diese Anleitung genau durch!
Lees deze instructies zorgvuldig door!



English
Français
Español
Deutsch
Nederlands

Important

Welcome to the HONEYWELL Family of Products

Your safe will provide years of safe and secure storage for your valuables.

For security:

- **Do not remove the Serial Number Tag** from the side of the safe.
- Set a new Passcode immediately.
- Store the keys and Passcode away from the safe.

The factory set Passcode for your safe is:


1 5 9 A

Important: You must always press letter A after entering Passcode.

Your Anti-Theft safe™ Includes


- ▶ 4 “AA” Batteries
- ▶ Removable Shelf (Model 2072)
- ▶ 1 Emergency Override Key / 2 Entry Keys (Models 2072 / 2073)
- ▶ 2 Emergency Override Keys (Model 2025)
- ▶ Protective floor mat
- ▶ Instruction manual

Overview



2072 / 2073

1. Key lock
2. Digital keypad
3. Red/Yellow/Green Lights
4. Safe door



2025

1. Opening knob
2. Override Key Lock cover
3. Digital keypad
4. Red/Yellow/Green Lights
5. Safe door

Opening Your Safe

The Passcode set at the factory is 159A. Use this Passcode the first time you open the safe.

1. Enter the Passcode on the keypad. The green LED lights.
2. Model 2025 - Turn the opening knob (Fig. 1) within 5 seconds, to the right (Fig. 2) and pull the door open. If you take no action within 5 seconds, the safe automatically relocks.
3. Models 2072/2073 - Insert the Entry Key into the key lock (Fig. 3), turn to the right (Fig. 4), and pull the door open. If you take no action within 5 seconds, the safe automatically relocks.
4. If batteries fail or you forget the Passcode, entry to the safe can be made using the Emergency Override Key.

Emergency Override Key:

Model 2025 - Remove the override lock cover (Fig. 5), insert Emergency Override Key, turn to the right and pull door open.

Models 2072/2073 - Insert Emergency Override Key into the key lock (Fig. 7), turn to the left and pull door open.

Programming your Personal Passcode

You can program your own Passcode. For your security, change the factory-set Passcode (159A) immediately.

Setting Your Passcode:

1. Press 159A (factory preset Passcode) and open the door.
2. Locate the red button on the inside lower edge of the door (Fig. 8).
3. Press the button; then release it and you will hear a beep.
4. Now press between 3 and 8 numbers that you wish to use as a Passcode, and confirm by pressing the letter "B". Be sure to write them down immediately, so you don't forget how to open the safe.
5. Your Passcode alone will now open the Safe; The factory preset Passcode will no longer open the Safe.
6. To open the Safe, push the numbers you have selected followed by the letter "A".

Closing and Securing your Safe

Do not over-fill the safe or obstruct the door from completely closing.

Closing the Door:

1. Close the safe door.
2. Model 2025 - To lock the safe, turn the opening knob to the left (Fig. 6).
3. Models 2072/2073 - To lock the Safe, turn the Entry Key to left (Fig. 7) and remove key.
4. To re-open, enter your Passcode.

Security Lockout:

The safe is designed to lock-out the keypad if the wrong Passcode is entered multiple times.

- After 3rd error: 20 second lock-out
 - 3 more errors: 5 minute lock-out
 - 3 more errors: 1 hour lock-out
- You can always use the Emergency Override Key to open the safe. See Opening Your Safe for instructions.

Illustrations

Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6




Fig. 7




Fig. 8




Fig. 9





Fig. 10



Checking Batteries

Checking Batteries

On the keypad, press *B*.

- If the red LED flashes, change the batteries within 2 months.
- If no LED lights, change the batteries immediately.

Changing Batteries

Changing batteries will not erase your Passcode.

1. Open the safe door and find the battery compartment on the back.
2. Model 2025 - Push on small tab (Fig. 9) and pull the cover off.
3. Models 2072/2073 - Slide the cover off the battery compartment (Fig. 10).
4. Properly replace batteries and put cover back into place.

Appropriate Use of Your Safe

- Your Anti-Theft safe™ is designed to provide protection against theft and minimal fire damage. It does not protect the contents from serious fire or water damage.
- For information on safes that provide protection from fire and water damage, see your Home Security retailer or visit our website at www.HoneywellSafes.com

Troubleshooting

- **Safe will not open with your Passcode:**
Open the safe using the Emergency Override Key and re-program your Passcode. See *Opening Your Safe and Programming Your Personal Passcode*.

Troubleshooting Cont.

- **No LED Lights:**
Model 2025 - Open the safe by removing the Emergency Override Lock cover (Fig. 5) and inserting the Emergency Override Key, and change batteries. See *Checking/Changing Batteries*.

Models 2072/2073 - Open the safe by inserting the Emergency Override Key into the key lock (Fig.7), open safe and change batteries. See *Checking/Changing Batteries*.

If you continue to experience problems or have questions regarding your safe, please contact SISCO Customer Service at 800-223-8566. Do not return safe to the retailer unless instructed to do so by Customer Service Representative.

Thank you!

Ordering keys for your safe

If a key becomes misplaced or you would like additional keys, you may conveniently purchase them from our Customer Service department.

You must supply the following information to assure accurate processing:

- Name / Address / Telephone
- Email address if available
- Safe Model Number / Serial Number
- Type of keys requested (Entry or Emergency Override)
- Number of keys requested
- Key Number (located on the lock)

Payment and Delivery

In the U.S., replacement keys are available for a fee and credit card orders are accepted by telephone and through our web site. Checks or Money Orders are required for orders received by mail and should be made payable to "SISCO". Contact our Customer Service department for costing information.

800-223-8566 (U.S.A & Canada)

Monday through Friday, 7:30 am to 4:30 pm

Pacific Standard Time

SISCO

2835 East Ana Street

Rancho Dominguez, CA 90221-5601 USA

Limited product warranty

If your Honeywell safe fails to operate because of a manufacturing defect any time up to five (5) years from the date of original purchase, we will, at our discretion, repair or replace the unit at no charge to the original owner. A copy of your sales receipt is required as Proof of Purchase.

The consumer must first contact SISCO® Customer Service (800-223-8566, USA and Canada; 310-638-1182 outside of USA and Canada, or via E-mail at customerservice@honeywellsafes.com during the Term of the Limited Warranty for authorization on the repair or replacement of the safe. For the repair of the safe, SISCO® Customer Service may provide approval for taking it to a local locksmith. For the replacement of the safe, the consumer must return it, prepaid, to SISCO® (2835 E. Ana St., Rancho Dominguez, CA 90221). SISCO® will replace the safe with a comparable model, shipping prepaid.

WHAT IS NOT COVERED

SISCO's® responsibility and the consumer's rights are limited to the repair or replacement of the defective safe, as stated above.

This Warranty does not apply if the product has been damaged by improper installation, neglect, accident, misuse, exposure to extremes of heat or humidity, terrorism, war, acts of God, or as a result of service or modification by other than an authorized service center. While your SISCO® safe is warranted to be free of mechanical defect during the Term of Limited Warranty, the Warranty does not apply to the finish of the safe.

SISCO® is not responsible for any costs associated with removing or installing this product.

SISCO® is not responsible for damage or loss of the contents of the safe nor for the unauthorized removal of contents.

SISCO® is not responsible for any damages incurred to the safe during shipment.

This Limited Warranty applies only to new SISCO® safes, purchased by the original owner, and is not transferable to second owners or "factory seconds" safes purchased by the consumer.

No implied Warranty of salability or fitness exists other than those descriptions provided on the packaging, instructions and advertising. No other covenants or warranties, either implied or stated, written or oral, are hereby present. Some states do not allow limitations on how long an implied Warranty lasts, so the above limitations may not apply to you.

This Warranty gives you specific rights and you may also have other rights which vary from state to state.

The Honeywell trademark for Home/Office Safes is used with permission. Honeywell Safes are distributed exclusively by SISCO®. Honeywell makes no representations or warranties with respect to this product or service. The Honeywell Trademark is used under license from Honeywell Intellectual Properties Inc. by SISCO®.

Home and Office Security Safes
Coffres-forts résidentiels et commerciaux
Cajas fuertes de seguridad para la oficina y el hogar

SISCO®

www.HoneywellSafes.com

US/Canada - Etats-Unis/ Canada - EUA/Canadá

2835 East Ana Street
Rancho Dominguez, CA
90221-5601 USA

US/Canada Toll Free:

Numéro sans frais aux Etats-Unis/ Canada:
EUA/Canadá llamada telefónica gratis:
800-223-8566

US/Canada - EUA/Canadá - Etats-Unis/ Canada:
310-638-1182

Fax - Facsímile:
310-638-6489

Email - Courriel:
CustomerService@HoneywellSafes.com

EUROPE - EUROPA

c/o - Atención:
Freightways Distributions B.V.
P.O. Box 3077
2220 CB Katwijk
The Netherlands
+31 71 4090721

Australia-l'Australie-Austrelien-Australië

c/o - Atención - p/a:
Customer Service Dept.
Master Distributors
11 Howleys Road
Notting Hill VIC 3168
03-9538-9200

Honeywell